



*Rewarding Learning*  
**ADVANCED SUBSIDIARY**  
**General Certificate of Education**  
**2018**

Centre Number

--	--	--	--	--

Candidate Number

--	--	--	--	--

# Physics

Assessment Unit AS 3A

*assessing*  
 Practical Techniques  
 and Data Analysis



SPH31

[SPH31]

**THURSDAY 3 MAY, MORNING**

## TIME

1 hour.

## INSTRUCTIONS TO CANDIDATES

Write your Centre Number and Candidate Number in the spaces provided at the top of this page.

Answer **all** the questions in this booklet. Rough work and calculations must also be done in this booklet. Except where instructed, do **not** describe the apparatus or experimental procedures. The Teacher/Supervisor will tell you the order in which you are to answer the questions. One hour is to be spent on four short experimental tests.

**After 12 minutes you must stop using the apparatus so that it can be rearranged for the next candidate.** At 14 minutes you will be instructed to move to the station for the next question.

At the end of the test a 4 minute period will be provided for you to complete your answer to any question, but you will not have access to the apparatus during this time.

## INFORMATION FOR CANDIDATES


The total mark for this paper is 40.

Figures in brackets printed down the right-hand side of pages indicate the marks awarded to each question or part question. You may use an electronic calculator.

For Examiner's  
use only

Question Number	Marks	Remark
1		
2		
3		
4		

Total Marks		
-------------	--	--



A diagram showing a vertical container with a thick base. Inside the container, there is a liquid represented by a series of horizontal dashed lines. An arrow points from the word "liquid" to the dashed lines, and another arrow points from the word "container" to the right wall of the container.

**Fig. 1.1**

- Diameter of container: \_\_\_\_\_ cm [2]

- Area = \_\_\_\_\_ cm<sup>2</sup> [1]

- $h =$  \_\_\_\_\_ cm [1]

Examiner Only	
Marks	Remark











(a)  $l$  has been set at 50.0 cm. Use the stopclock to find a reliable value for  $T$  at this length. Shorten the string to a second value of  $l$  and repeat. Record all your results in **Table 4.1**.

$l/\text{cm}$		$T/\text{s}$	$T^2/\text{s}^2$
50.0			

8









Permission to reproduce all copyright material has been applied for.  
In some cases, efforts to contact copyright holders may have been unsuccessful and CCEA  
will be happy to rectify any omissions of acknowledgement in future if notified.



*Rewarding Learning*

**ADVANCED**  
**General Certificate of Education**  
**2018**

---

# **Physics**

Assessment Unit AS 3A

Practical Techniques and Data Analysis

**[SPH31]**  
**THURSDAY 3 MAY**

---

## **APPARATUS AND MATERIALS LIST**

**PHYSICS UNIT 3 (AS 3A)**  
**APPARATUS AND MATERIALS REQUIRED FOR PRACTICAL ASSESSMENT**

**CONFIDENTIAL**

This document gives preliminary information on the apparatus and materials required for the AS Practical Assessment.

**Information about the apparatus and materials required for this assessment must NOT be communicated to students.** If apparatus/materials have their serial code and/or manufacturer specified then it is essential that centres use this exact apparatus/material.

On receipt of this APPARATUS AND MATERIALS LIST, centres must contact Gavin Gray, ggray@ccea.org.uk immediately if they have difficulty in sourcing the specified apparatus or materials.

Teachers will be given detailed instructions for setting up the experiment in the *Confidential Instructions for Physics (Advanced Subsidiary) Practical Test*, to which they will have confidential access from April 2018.

**Teachers will have confidential access to a copy of the experimental test two working days (48 hours) before the start of the assessment.**

The AS 3 Practical Techniques Assessment is a test of practical skills consisting of 4 short experimental tests (40 marks). The duration of the assessment is 1 hour.

The apparatus in the following list will allow for **one experiment** to be set up for the practical test which makes up questions 1–4. In other words, each set of apparatus (as listed on **pages 4 and 5**) will accommodate four candidates when doing the circus of experiments.

The apparatus can be used for alternative sessions according to the following schedule:

### **3 May 2018 Physics AS 3A (SPH31)**

(Main Session) **9.15 am–10.15 am**

(First Alternative) **10.30 am–11.30 am**

(Second Alternative) **11.45 am–12.45 pm**

(Third Alternative) **1.15 pm–2.15 pm**

(Fourth Alternative) **2.30 pm–3.30 pm**

One set of apparatus for AS 3A (SPH31) will therefore be sufficient for twenty candidates on **3 May** if the Main Session and all four alternatives are used. A laboratory may contain one, two, three or more sets of apparatus. This means that four, eight, twelve or more candidates can be accommodated in the same session. **To maintain the confidentiality of details of the practical tests, candidates entered for any of the alternative sessions must be segregated within the centre so that there can be no communication with candidates who have taken an earlier test in any centre.**

### **IMPORTANT NOTICE**

**Centres are urged to order items needed for the Physics Practical Tests from the suppliers as soon as possible.**

**Question 1**

- Gas jar with diameter 4–6 cm, capacity at least 200 ml, mass less than 300 g
- Half metre rule
- Vernier calliper
- Electronic balance capable of reading up to 500 g to nearest 1 g or 0.1 g
- 250 ml beaker
- 150 ml salt water solution (approx.  $1.1 \text{ g cm}^{-3}$ )
- 250 ml graduated cylinder
- Insulating tape


**Question 2**

- Thermistor EPCOS B57164K471J or similar (KED471). RS 191-2229
- 1.5 V D cell
- Digital milliammeter 0–20 mA to 0.01 mA
- Digital voltmeter 0–20 V to 0.01 V
- Connecting leads with 5 mm plugs at each end  $\times 6$
- 250 ml beaker
- Water at room temperature
- Crushed ice
- Retort stand & clamp
- Switch
- Method of clamping the thermistor into retort stand, e.g. component holder with crocodile clips.
- Dessert spoon/soup spoon
- Thermometer with range  $-10^{\circ}\text{C}$  to  $110^{\circ}\text{C}$



### Question 3

- 20 cm convex lens and holder
- Constructed illuminated object (washer with internal diameter  $10 \pm 1$  mm) and crosswires as used in 2011 A2 3 shown in **Fig 3.1**
- Screen – plain white paper
- Metre rule
- 30 cm rule



**Fig. 3.1**

### Question 4

- Pendulum bob, string and split cork
- Retort stand, clamp and boss
- Stopclock to 0.01 s
- Metre rule



*Rewarding Learning*

**ADVANCED SUBSIDIARY (AS)  
General Certificate of Education  
2018**

---

# **Physics**

Assessment Unit AS 3A

Practical Techniques and Data Analysis

**[SPH31]  
THURSDAY 3 MAY**

---

**CONFIDENTIAL  
INSTRUCTIONS**

## 1 Confidential Instructions

These instructions will give detailed guidance on setting up and testing the apparatus and materials to be used. **Again, information contained within the Confidential Instructions must not be relayed to candidates under any circumstances.** If at this point, centres find that the testing process produces results different to those specified in the Confidential Instructions, they must contact the CCEA Science Subject Officer (ggray@ccea.org.uk) immediately.

## 2 Final Apparatus Testing

The practical assessment question paper will be made available to the Head of Physics **two** working days before the timetabled starting time so that teachers and technicians can carry out a final test on the experiments. If on checking the apparatus gives unexpected results, the CCEA Physics Subject Officer should be contacted immediately (ggray@ccea.org.uk). If the problem cannot be resolved, then the centre must e-mail the CCEA Physics Subject Officer stating the centre name and number, the specific nature of the problem and the range of anomalous results produced. CCEA will respond by acknowledging receipt of the e-mail. If you do not receive a response within 24 hours, please contact the CCEA Physics Subject Officer by telephone (028 90261200 Ext 2270) to confirm that CCEA has received your e-mail.

## 3 Practical Assessment AS 3A

The AS 3A Practical Techniques Assessment is a test of practical skills comprised of 4 short experimental tests. The duration of the assessment is 1 hour. Some of this time will be set aside for supervisors to re-set the apparatus ready for the next candidates. The assessment should be run as a circus of experiments with candidates moving to the next experiment at the designated time. The assessment should be timed as follows:

Questions	Time
Q1 (Short practical test)	12 minutes
Changeover and practical write-up	2 minutes
Q2 (Short practical test)	12 minutes
Changeover and practical write-up	2 minutes
Q3 (Short practical test)	12 minutes
Changeover and practical write-up	2 minutes
Q4 (Short practical test)	12 minutes
Changeover and practical write-up	2 minutes
End of test write-up	4 minutes

At the end of each 12 minute period, candidates must stop using the apparatus. During each 2 minute changeover period candidates may write up anything they have not completed however they will not have access to the apparatus.

At the end of the test a 4 minute period is provided for candidates to complete their answer to any question, however they will not have access to the apparatus.

#### **4 After the Practical Assessments**

When the individual exam sessions have finished, please return the AS 3A practical scripts together with the corresponding advice notes to the examinations officer (EO). We will collect these by the day after the examination. If we don't, please contact us immediately to arrange another time for collection.

Where the centre finds that a candidate may have been disadvantaged because the apparatus did not function as intended, the supervising teachers should make a report to the EO. The EO will forward the confidential report on the issue and the candidates affected to the centre support section at CCEA for special consideration. Candidates should be identified by their examination number.

#### **IMPORTANT NOTICE**

**Centres are urged to order items needed for the Physics Practical Tests from the suppliers as soon as possible.**

**Question 1****Requirements**

- Gas jar with diameter 4–6 cm, capacity at least 200 ml, mass less than 300 g
- Half metre rule
- Vernier callipers
- Electronic balance capable of reading up to 500 g to nearest 1 g or 0.1 g
- 250 ml beaker
- 150 ml salt water solution (approx.  $1.1 \text{ g cm}^{-3}$ )
- 250 ml graduated cylinder (teacher use only)
- Insulating tape

**Preparation**

Place some insulating tape over the scale of the beaker. Use the graduated cylinder to measure 150 ml of the salt solution and put it into the gas jar.

Place the gas jar, half metre rule, vernier callipers, empty beaker and electronic balance on the bench at workstation. Ensure all instruments are zeroed as appropriate.

**Action at changeover**


Pour the 150 ml salt solution into the gas jar. Place apparatus as at start of experiment with all instruments zeroed.

**Question 2****Requirements**

- Thermistor EPCOS B57164K471J or similar (KED471). RS 191–2229
- 1.5 V D cell
- Digital milliammeter 0–20 mA to 0.01 mA
- Digital voltmeter 0–20 V to 0.01 V
- Connecting leads with 5 mm plugs at each end  $\times 6$
- 250 ml beaker
- Water at room temperature
- Crushed ice
- Retort stand and clamp
- Switch
- Method of clamping the thermistor into retort stand, e.g. component holder with crocodile clips.
- Dessert spoon/soup spoon
- Thermometer with range  $-10^{\circ}\text{C}$  to  $110^{\circ}\text{C}$


**Preparation**

Set up the circuit shown in **Fig 2.1**.




**Fig. 2.1**

Attach the thermistor to the crocodile clips of a component holder. Clamp the component holder and thermometer in a retort stand and place in a beaker of water at room temperature as shown in **Fig. 2.2(a)** and **(b)**.



**Fig. 2.2(a)**

Source: Chief Examiner



**Fig. 2.2(b)**

Source: Chief Examiner

**Action at Changeover**

Replace the iced water in the beaker with water at room temperature. To do this slide the retort stand towards the edge of the bench so that the beaker can be lowered off the edge of the bench as shown in **Fig 2.3**.



**Fig 2.3**

Source: Chief Examiner

### Question 3

#### Requirements


- 20 cm converging lens and holder
- Constructed illuminated object (washer with internal diameter  $10 \pm 1$  mm) and crosswires as used in 2011 A2 3
- Screen – plain white paper
- Metre rule
- 30 cm rule

#### Preparation

##### Illuminated object (washer and cross) construction.

Measure the height  $H$  of the centre of the lens, mounted in the lens holder above the surface of the bench. Take a sheet of stiff card and use a sharp knife to cut a square aperture of side 40 mm so that the centre of the square is a distance  $H$  from the marked edge of the card. The width  $W$  of the card depends on the dimensions of the lens holder.

Cut a piece of tracing or greaseproof paper about 60 mm square. In the centre of this square use a fine felt tip pen ( or similar) to mark an “X” with the arms at least 10 mm long. Place the washer over the “X” so that the intersection of the arms is at the centre of the circular hole in the washer. Using transparent self-adhesive tape, attach the washer to the tracing paper. Avoid covering any part of the hole in the washer. Place the tracing paper on the card so that the washer is at the centre of the 40 mm square aperture, with the washer inside the opening. Tape the tracing paper to the cardboard. The completed object is illustrated in **Fig 3.1**



**Fig. 3.1** Washer and “X” object (not to scale)

Place apparatus at workstation. Check that the magnification of the object is approximately 2 when the object distance is 30 cm.

#### Action at Changeover

Dismantle all apparatus and leave as at start of experiment.

#### Question 4

##### Requirements

- Pendulum bob, string and split cork
- Retort stand, clamp and boss
- Stopclock to 0.01 s
- Metre rule

##### Preparation

Tie the pendulum bob to the end of the string. Thread the pendulum string through the split cork. Position the split cork in the jaws of the clamp. Set the length of the pendulum to be 0.500 m. Leave the metre rule and stopclock beside the pendulum.

##### Action at Changeover

Return the length of the pendulum to 0.500 m and rezero the stopclock.



